

2

ESS3-SM ASSEMBLY

MOUNTING HARDWARE (INCLUDED):

- ½ 13 x 4" zinc coated bolts (QTY. 4).
- ½" flat washers (QTY. 8)
- ½ 13 nylon locking nuts (QTY. 4)

HANDRAIL ASSEMBLY

- The lower and upper handrails are held together by two split collars with 3/8" holes drilled in them. These holes are spaced 1.5" for a total adjustment of 12" up or down.
- Use the phillips head screws (QTY. 8) for the top and bottom hand rail. 4 screws on top, 4 screws on bottom.
- Adjust the handrail to a height that works best for you. The height can be adjusted from 60"-72".
- Once handrail is adjusted to the desired height, place it over the 7/8" x 7/8" x 7" bar stock on the top bracket assembly and tighten using the 2 set screws.

ATTACHING SIDE MOUNT BRACKETS TO FRAME

 \bullet Secure the side mount bracket to the frame using the ½" bolts, flat washers and nylon nuts.

ATTACHING STEPS TO SIDE MOUNT BRACKET

- Secure the step weldment (1.25" tubing) to the top bracket using the uclamp bracket and the 3/8" bolts and locking nuts (QTY 2).
 - These steps are adjustable 2" up or down to suit your preference.

LOCTITE

• We recommend applying mid-grade Loctite to all connections. This will help prevent screws and bolts from coming loose while traveling.

IF FURTHER ASSISTANCE IS NEEDED, PLEASE CONTACT OUR OFFICE.

Email: <u>info@easystepsystem.com < mailto:info@easystepsystem.com ></u>

Phone: 800-966-1502

SHEET 2 OF 2

) -