

2

ESS4 ASSEMBLY

MOUNTING HARDWARE (NOT INCLUDED): may be purchased at local hardware store.

- ½-13 Zinc coated bolts. Length is to be 1.5" longer than the depth of the mounting surface. (QTY. 6)
- ½" Flat washers (QTY. 12)
- An additional 4 washers may be purchased for space in between top and bottom brackets (SEE PICTURE FOR DETAILS)
- ½-13 Nylon locking nuts (QTY. 6)
- An additional 4 nylon nuts may be purchased for space between top and bottom bracket (SEE PICTURE FOR DETAILS)

HANDRAIL ASSEMBLY

- The lower and upper handrails are held together by two split collars with 3/8" holes drilled in them. These holes are spaced 1.5" for a total adjustment of 12" up or down.
- Use the phillips head screws (QTY. 8) for the top and bottom hand rail. 4 screws on top, 4 screws on bottom.
- Adjust the handrail to a height that works best for you. The height can be adjusted from 60"-72"
- Once handrail is adjusted to the desired height, place it over the 7/8" x 7/8" x 7" bar stock on the top bracket assembly and tighten using the 2 set screws.

ATTACHING BRACKETS TO TONGUE

• Secure the top and bottom brackets to the tongue/frame with the ½" bolts, flat washers, and nylon nuts (NOT INCLUDED)

ATTACHING STEPS TO BRACKET

- Secure the step weldment (1.25" tubing) to the top bracket using the u-clamp bracket and the 3/8" bolts and locking nuts (QTY 2).
- These steps are adjustable 2" up or down to suit your preference.

LOCTITE

• We recommend applying mid-grade Loctite to all connections. This will help prevent screws and bolts from coming loose while traveling.

IF FURTHER ASSISTANCE IS NEEDED, PLEASE CONTACT OUR OFFICE.

Email: info@easystepsystem.com <mailto:info@easystepsystem.com>

Phone: 800-966-1502

HEET 2 OF 2

R

2

1